

AppNeta Devices


All devices provided are Bootstrapped, which means they are automatically connected to a dedicated Fuze instance on the AppNeta cloud or portal. You only need to connect the power and network to the device and confirm from the LED that the device is online and ready.

Note: You should then contact your Fuze Network Consultant to activate the device, which will assign the device into an organization dedicated to you.

Powering on M35

To start your M35 device:


1. Power on. Appliance is fully booted when the status LED turns to one of three ready states
2. Connect to network. Cable the appliance according to the instructions in the next section. Status LED turns to green heartbeat when connected



Powering on M50

To start your M50 device:

1. Power on. Appliance is fully booted when the status LED turns to one of three ready states
2. Connect to network. Cable the appliance according to the instructions in the next section. Status LED turns to green heartbeat when connected



heartbeat	Status	Actions required
● ● ● ●	Connected to APM	None. Successfully connected!
▬	Unconfigured	Configure monitoring point. See docs.appneta.com/empsetup
● ● ● ●	Can't connect to APM	Troubleshoot connection. See docs.appneta.com/troubleshoot

Cabling

Network connection ports on monitoring points are used for connectivity to APM and for delivery monitoring.

This diagram shows the network connection port on the monitoring point connected to a switch on your network like other LAN clients. The network must provide connectivity to APM.

Cabling - Out of Band

Out-of-band Usage monitoring requires that your switch is capable of port mirroring and that a mirror source and a mirror destination, also known as Switched Port Analyzer (SPAN) ports, have been configured. The switch's mirror source port is the one being monitored, typically the aggregation point.

This diagram shows how to cable a Usage monitoring port for out-of-band Usage monitoring.

Logging into AppNeta Performance Manager

To access the Fuze RTNM Portal you can visit fuze.pm.appneta.com and login with the account details you have been provided.

If you haven't received your account details by way of a welcome email from AppNeta, please contact your Fuze Network Consultant.

1. Visit: fuze.pm.appneta.com
2. Enter User ID
3. Enter Password
4. Click Log in

Note: If password has been forgotten, use the provided link